CARE AND MAINTENANCE

- 1. Fabric cover should be cleaned by brush with neutral detergent like soap.
- 2. Check the screws at regular intervals. If parts are damaged or appear broken, stop using immediately.
- 3. Please follow the operation instruction strictly while installation and uninstallation to avoid unnecessary damage of the stroller resulting in harm to your child.



- 1. The parent/guardian must read these instructions carefully before using the product and keep it for future reference for the safety of your child.
- 2. Never leave your child unattended in the stroller.
- 3. This product is suitable for the child aged 0-36 months only.
- 4. Do not fold the stroller when the child is in it.
- 5. Must use the front handrail when riding.
- 6. Do not leave the stroller on the ramp.
- 7. The maximum load carrying capacity of the basket is 2kgs.
- 8. Any load placed on the handle bars will affect the stability of the stroller.
- 9. Do not remove or adjust any parts of the stroller when the child is in it.
- 10. To avoid suffocation, keep any plastics covering or bags for away from your child.



Imported & Marketed By:

R FOR RABBIT BABY PRODUCTS PVT. LTD.

Add: 708, 7th Floor, Pinnacle Business Park, Corporate Road, Prahlad Nagar, Ahmedabad, Gujarat 380015
C: +91-79-410-57595 | W: www.rforrabbit.com

E: customercare@rforrabbit.com

"Pocket Air Stroller"
for Installation

Scan & Search





POCKET AIR STROLLER

Air Light Stroller For Easy Travel








Installation & User Manual

Read the instructions carefully before using the stroller and keep this manual for future reference. Note: The safety your child and product can be compromised if the instructions stated in manual aren't thoroughly followed.

PARTS




- (1) Canopy
- (2) Handle Bar
- (3) Folding Lock
- (4) Folding Button
- (5) Backrest Adjustment Wabble
- (6) Front Bar
- (7) Button to remove Front Bar


- (9) One pull Release Buckle
- (10) Foot Rest
- (11) Foot rest Adjustment Clip
- (12) Basket
- (13) Button to release front wheels
- (14) Front Wheels
- (15) Rear Wheels

PARTS

1. Frame




2. Bumper Bar




▶ Opening the stroller

- 1. Take out the stroller and unlock the hook.
- 2. Lift the handle bar up slightly to expand the frame. When you hear a "click" sound, the stroller will be opened completely







USAGE INSTRUCTIONS

▶ Bumper bar instructions


- 1. Installation: Put the bumper into the plastic holder of the stroller until you hear a click sound.
- 2. Uninstallation: Press the quick release button on both sides of the bumper using both hands and pull it towards you to take it off.



Page 4 Page 5

▶ Safety belt instructions


- 1. Usage of the safety belt: Combine 1 and 2 as shown in the picture to get 3. Then insert 3 into the seat belt center buckle as 4.
- 2. Opening the safety belt: Press the button at the center of the seat belt to open it.
- 3. Height adjustment: Insert the shoulder belts into or not into different holes ("a" "b") on the seat to adjust the height of the safety belt; Or release or shorten the length of the shoulder belt, so that can adjust the belt height for different height of the child.



USAGE INSTRUCTIONS

▶ Front wheel instructions

- 1. Installation: Insert the front wheel components with the front tube until you hear a click. Then pull the wheel in the opposite direction to make sure the front wheel is locked. Do the same for the other wheel to install.
- 2. Uninstallation: Lift the front wheel tube, and press the quick release button, then pull the front wheel down.



Page 6 Page 7

▶ Footrest adjustment

At the same time, push the left and the right adjustment button which are on the side of the footrest cover, then pull the footrest up and down.



USAGE INSTRUCTIONS

▶ Backrest adjustment


Backrest can be adjusted by fastening or loosening the backrest belt while pressing the middle button indicated in the image.




Page 8 Page 9

▶ Brake instruction

- 1. Keep pressing the brake until the brake block click into brake gear completely, indicating the stroller is braked.
- 2. Lift the brake up to move the stroller.








USAGE INSTRUCTIONS

▶ Folding instruction

- 1. Unfold the canopy and push the press the lock button on the handle bar while pressing the stroller down.
- 2. Secure the folded stroller using hook on the left hand. Press the hook till you hear a click indicating the stroller is folded and in place.



Page 10 Page 11