

BRAKING TECHNIQUES

- To release, shuffling one foot on the ground or press the rear wheel brake positioned over on the heel (models with integral brake).
- Brake after repeated or constant use may be hot. Do not touch it directly after braking.

BASIC SAFETY RULES

- Always follow the rules of the road.
- While driving, do not hold the occupants of motor vehicles and bicycles.
- The age group of the this scooter is 2 years & above.
- Avoid driving on wet, pebbly surface on which there are oil stains, etc.
- Avoid driving in the dark.
- Pay attention to the condition of the scooter.
- Make sure all screws are tight.
- Do not modify the scooters, since it can harm the child.
- You should check whether there are any splinters and cracks.
- It is suggested to use Safety Helmet and Wrist, Elbow and Knee Protectors.



Designed & Marketed By:


R FOR RABBIT BABY PRODUCTS PVT. LTD.

Add: 708, 7th Floor, Pinnacle Business Park, Corporate Road, Prahlad Nagar, Ahmedabad, Gujarat 380015

C: +91-79-410-57595 | W: www.rforrabbit.com | E: customercare@rforrabbit.com

Manufactured by: PlayWay Systems

Add. 4/B, Maninagar, Nr. Ashok Garden, Mavdi Plot, Rajkot, Gujarat-360007



*Picture shown is for illustrative purpose only. Actual product may vary from image.




ROAD RUNNER DRIFT

Kick Scooter for Outdoor Fun

Installation & User Manual


IMPORTANT – KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE.
FAILURE TO OBSERVE THESE INSTRUCTIONS MAY AFFECT THE SAFETY OF YOUR CHILD!

PARTS




INSTALLATION

1




Pull the lever to loosen the clamp and lift it to unfold and open the scooter.

2




Push back the lever to tighten the clamp.

3




Insert the handle into the scooter till you hear a click. Pull back both the clamps on the handle to lock it in place.

4




Push the button and press the handle up or down to adjust it as per the desired height.

5



Pull back both the clamps on the handle and footrest to unlock the handle of the scooter.

6



Pull the lever on the footrest and bend the handle of the scooter to fold and store easily.