

130mm



R for Rabbit[®]
The Amazing Baby Company

INSTRUCTION MANUAL

ROAD RUNNER



NOTE : THE MANUAL SHALL BE CAREFULLY READ AND UNDERSTOOD BEFORE
USING SCOOTERS.
IT IS SUGGESTED TO USE SAFETY HELMET AND WRIST, ELBOW AND KNEE PROTECTORS.



R for Rabbit[®]
The Amazing Baby Company

IS9873



PART : 1

CM/L-7200208498

Marketed By:

R FOR RABBIT BABY PRODUCTS PVT.LTD.

708,7th Floor, Pinnacle Business Park, Corporate Road,

Prahlad Nagar, Ahmedabad, Gujarat 380015

079-410-57595 | www.rforrabbit.com | customercare@rforrabbit.com

Manufactured By: **PLAYPIPERS INDUSTRIES LLP**

Sai Estate, Plot no 2 & 3, Survey no 139 & 140, Village: Vasna Chancharwadi,

Taluka: Sanand, Ahmedabad, Gujarat, 382213

185mm

ROAD RUNNER

GENERAL INFORMATIONS

ASSEMBLING AND UNFOLDING THE SCOOTER SHALL ALWAYS PERFORMED BY AN ADULT PERSON.

Step to unfold the scooter

1 . Open the box and take out the folded scooter (Fig. 1)



Fig.1

2. Slide the black sleeve to unlock the handle for adjusting it in vertical position. (Fig 2)




Fig.2

3. Now hold the handle and make adjust it at an angle of 90 degree.(Fig 3) (Fig 4)




Fig. 3



Fid.4

ROAD RUNNER

4. Now adjust the height of the handle by pulling it up and let it stop at a fixed height with the help of any of the stopping holes in the rod




Fig. 5

5. Make your child know about the brakes which are at the top of rearwheel. (Fig 6)




Fig.6

RIDE

You ride on the scooter by pushing the foot. When you want to move, just push off.

MANEUVERING SCOOTER

Before driving, check that all elements are well assembled. T-shaped handlebar is used to maintain balance while driving and turning. In order to change direction to the left - turn the handlebar to the left in order to change direction to the right - turn the handlebar to the right.

ROAD RUNNER

BRAKING TECHNIQUES

To release, shuffling one foot on the ground or press the rear wheel brake positioned over on the heel (models with integral brake).

Brake after repeated or constant use may be hot. Do not touch it directly after braking.

BASIC SAFETY RULES

- Always follow the rules of the road.
- While driving, do not hold the occupants of motor vehicles and bicycles.
- Children under the age of eight should ride a scooter under adult supervision
- Learn everything slowly. When you lose balance, stop and start driving again.
- Avoid driving on wet, pebbly surface on which there are oil stains, etc.
- Avoid driving in the dark.
- Pay attention to the condition of the scooter.
- Make sure all screws are tight.
- Do not modify the scooters, since it can harm the child.
- You should check whether there are any splinters and cracks.
- It Is Suggested to use Safety Helmet and Wrist, Elbow and Knee Protectors.

ROAD RUNNER

WARRANTY INSURANCE

Damages caused by accidents, misuse or improper repair of the product; worn parts; parts not lubricated, scratched or damaged by corrosion as well as installation of non-original spare parts.

Complaints concerning worn wheels, worn brakes and damaged or broken bearings **WILL NOT BE ACCEPTED** (it refers to consumable parts).

This product is not intended to acrobatic and extreme performances (umping over obstacles, jumping down etc.). Manufacturer is not responsible for damage caused to health and property, which may result from such use.

Any complaint must be made immediately after discovery of the defect, in the shop where scooter had been purchased.

Consumer cannot continue to use the product, in which he had stated a defect.

Only products cleaned and without any dirt can be claimed.

Defected items should be delivered in the durable (best original) packaging, with item code.

While lodging complaint, the proof of purchase must be shown.

Seller shall submit a written complaint about the scooter state, in which the exact reason of complaint is described. The right to make a complaint expires after the warranty period.